



Castle Access Panels & Forms Inc

135 Wendell Ave

North York, ON M9N 3K9

Phone: (905) 738-8089

Email: orders@castleaccesspanels.com

GRG MAINTENANCE & REPAIR

1. MAINTENANCE

The following maintenance may be required to keep GRG Column Cover in good working order. These instructions are on the basis that surfaces have been suitably treated.

Maintenance Work to be carried out

The maintenance of this finish is similar to most painted plaster work. Dirty marks should be washed off with clean water and a mild detergent if the surfaces are suitably treated. If this is not possible and marks persist, re-painting may be necessary as the only alternative.

Periods of Maintenance

As and when required.

2. REPAIRS

Minor Surface Damage

If the surface of GRG is scratched or chipped it will need to be filled prior to repainting. This can be done with normal plaster repair, taking care to follow manufacturer's instructions. When dry, repaired area may be rubbed down with fine abrasive paper and over-painted in the original manner.

Major Damage

If the surface of GRG is punctured it will be necessary to provide packing to fill against. This is done in a similar manner to car body repairs using such materials as wire mesh, expanded metal, plasterboard and bonding plaster or polyurethane foam as backing materials. Repairs are then concluded as detailed above. In the event that a panel is damaged such that its shape and rigidity are lost it may need to be replaced. In that case, contact the manufacturer.